

Part 1: Set the FTP Server

1. You should install wftpd32.rar, then decompression it
2. After you open the software, click “Security->Users/rights” you will see as follows.



3. You need create a new user, please click to “New User..”, then you should fill in the informations in order. For example, you could set “1” as the user and password, and fill in the software directory “D:\”(please put the firmware in D disc). After completed, then press “Done”. (Tips: please do not close this software in the process of operating)

Part 2: Set your computer's IP address

1. Find the “network neighborhood” in your computer
2. click the right mouse button and select Properties.
3. Choose “Local connection” and enter into it.



- Click “属性” as above.
 (“属性” which means property.)




- Click “Internet 协议”, setting your PC IP:192.168.10.61
 “Internet 协议” which means Internet protocol
 The IP address you could set as you want, but you should set 192.168.10.xx

Part 3: Set your IP Phone

- Put you PC connect to phone’ s LAN port and reboot your IP Phone.
- In the process of reboot, you should press # and power on till the LCD display POST MODE.

Part 4: Starting to upgrade

- Get into DOS MODE in your computer, then you should input “telnet 192.168.10.1”. You will see the config page as below.



- You should input “2” then press enter key(2)

4. Input your computer IP address then press enter key(192.168.10.61)
5. Input your firmware' s name(It would be best set the name short)
6. Input your FTP Server User name(In this test I set the user name and password "1", so I should Input "1")
7. Input "1"
8. If you see the upgrade is complete, you may need to reboot your IP Phone